


Julia

collection

Standing Desk

ITEM NO. Z6DKDZ0750-UK



UK
CA

UK REP

Company:YH Consulting Limited

Address: C/O YH Consulting Limited Office 147,Centurion House ,
London Road , Staines-upon-Thames, Surrey , TW18 4AX

HULALA®
HOME



CONTROLLER
INSTRUCTIONS

MAINTAINANCE AND WARNINGS

Thank you for purchasing the Standing Desk.

Please read the instructions and warnings carefully before use, to ensure safe and satisfactory operation of this product.



Before You Start

Please follow the steps below:

- ⚠️ Unbox the package and check if all parts and accessories are complete.
- ⚠️ If you find something missing, stop installing and contact your supplier immediately.
- ⚠️ Please do not completely tighten all the hardware until the entire assembly is completed! Be sure to tighten all the hardware once the assembly completed.
- ⚠️ NOTE: Should be assembled on soft surface to keep balance.

After-Sales Service

- If you encounter any issues or need technical support during use, please contact our after-sales team. We offer long-term maintenance and warranty services.



Warranty

- ⚠ We strive to our high , quality products, and we also try our best to satisfy each and every customer that orders from us with product or service as needed. We provide 30 days warranty starting from the time you receive the item. Each customer must provide a record of their order such as the order number, or item receipt for any items that are out of the warranty period you may also still receive replacement parts by purchasing them with our company if they are available.
- ⚠ Are you having difficulty with assembly? Missing parts? Please send email with your order No to **customerservice@hulalahome.com**
- ⚠ For return, please check the return policy with the retailer or market place you bought from. Appreciate your purchasing from us. Pop up your life by our furniture piece!

Daily Maintenance

- Keep furniture away from heat.
- Do not clean furniture with harsh cleansers or polish. Do not use detergents, Solvents, abrasives. spray packs or leather cleaner. Use non-color mild soap with warm water clean spills(Mix 1:10 soap to water)
- Do not place furniture under direct sunlight, material will possibly fade over time.
- Do not use on site dry Cleaning machine.
- Children should not climb or jump on the furniture.
- Do not write on furniture without a padded barrier to protect the surface.
- Not for commercial use, For residential use only.


Exploded Diagram




ITEM NO. Z6DKDZ0750-UK



Scan to get the
installation video




Installation:
15 minutes.



Requires 2 People
for Assembly

Parts List (Carton A)

A ×1




Top Panel

1 ×12+1 (spare)



Bolt Ø6x12mm


2 ×1



Wrench

Parts List (Carton B)


B ×2



Foot Box


ASSEMBLY INSTRUCTIONS

Step 1




Step 2

Put foot box into the bottom of table and carefully slide it to both sides respectively until it is completely aligned on both sides.




Step 3

1		x 8
2		x 1




Step 4




1. Pull the motor cable out through the holes of top panel(A).
2. Connect the power cord as shown in the diagram.

Step 5

The wires need to be securely fastened with wire clips.




Step 6



Note:

The operation takes two adults to complete.





Flip the products forward in order, as shown.

Step 7



controller
needs to be reset





Reset Operation:

1. Press and hold the "▼" button for 5 seconds until "RST" appears on the display.
2. Press and hold the down "▼" button until you hear a "di" and the display shows the lowest height. During this process, the desk will rebound by about 10 mm. The controller will only function normally after the reset is complete.

1. Insert the power cable into the adapter and turn on the power supply.
2. Once the power is on, you'll need to restore the settings.

Step 8

1  x 4




For details, refer to the Controller Manual.

1. Press the rise button to raise the tabletop.

Tighten bolts (1)100%  x 2 

After raising the desktop, lock all the Bolts from the bottom.

Step 9




WARNING:
Do not place hands or objects
on top to prevent injury or danger!

CAUTION:
The sound you hear when activating the lifting function is
normal and is caused by the high speed of the motor.

WARNING:
1. The load of the lifting table must be less than 200 LBS!
2. When raising or lowering the tabletop, ensure that the
tabletop remains stationary and does not move!

Step 10





If you have any questions or concerns,
don't hesitate to reach out to us.

customerservice@hulalahome.com